

How do I connect my other AV devices when installing a free to view digital tv set top box?

The free to view digital tv set top box is likely to be one of a number of AV devices that need to be connected to your television screen. Typically this might include a recording device (VCR or DVD recorder) and a play-only device (VCR or DVD player).

The following diagram provides the best way to connect your AV equipment when installing your digital tv set top box. If your television screen does not have sufficient AV inputs, ask your retailer about an AV switcher to enable you to connect more than one device to a

single AV input on your television screen. Alternatively, you can switch through a home theatre amplifier. Just remember that some televisions and switchers offer a variety of AV connectors so the best connection method should be selected from the tables set out in this brochure.

